




## Supplemental Panic Output Wiring Instructions



The panic output relay on the Utility Controller circuit board is intended as an interface for communication with Isimet notification devices or other digital control systems. This circuit is not intended to operate external devices such as other relays, solenoids & or shunt trips.

When project specifications indicate that devices are to operate or "not" operate through this circuit. Then the operating circuit for those devices should utilize Isimet normally open / normally closed relays Model #I-SRI (RIBMN24C) (w/o switch) remotely located with operating power supply provided separately from Isimet control units.

**NOTICE: Relay MUST be located remotely from the control unit.**

July 2007